



D 1 Power Window SW (Front RH)
D 2 Power Window Regulator Motor (Front RH)
D 3 Door Lock Assembly (Front Passenger's Side)

E 1 Power Window SW (Front LH)
E 2 Power Window Regulator Motor (Front LH)
E 4 Door Lock Assembly (Driver's Side)

F 1 Door Lock Assembly (Rear RH)

G 1 Door Lock Assembly (Rear LH)

H 1 Door Courtesy SW
H 2 Fuel Suction Pump and Gage Assembly
H 3 Speed Sensor (Rear RH)
H 4 Speed Sensor (Rear LH)
H 5 License Plate Lamp (RH)
H 6 License Plate Lamp (LH)
H 7 Center Stop Lamp
H 8 Front Seat Outer Belt (LH)
H 9 Front Seat Outer Belt (RH)
H 12 Side Airbag Sensor (LH)
H 13 Side Airbag Squib (LH)
H 14 Side Airbag Squib (RH)
H 15 Side Airbag Sensor (RH)
H 16 Curtain Shield Airbag Squib (RH)
H 17 Curtain Shield Airbag Squib (LH)
H 18 Front Seat Inner Belt
H 19 Back Door Lock Assembly
H 20 Rear Combination Lamp (RH)
H 21 Rear Combination Lamp (LH)
H 22 Junction Connector
H 23 Junction Connector
H 24 Fuel Sender Gage

I 1 Room Lamp

J 1 Rear Window Defogger
J 2 Rear Wiper Motor

K 1 Rear Window Defogger

Position of Parts in Body <LHD 5-Door>



